



# **External Control Command Specifications**

## **DuraVision® PT-LAN51**

**Remote Controlled Pan & Tilt Head**

## Table of contents

|             |   |           |
|-------------|---|-----------|
| 1           | External control protocol .....                       | 3         |
| 1.1         | <b>Communication device</b> .....                     | <b>3</b>  |
| 1.2         | <b>Communication settings</b> .....                   | <b>3</b>  |
| 1.3         | <b>Communication protocol</b> .....                   | <b>3</b>  |
| 1.4         | <b>Packet format</b> .....                            | <b>3</b>  |
| 1.4.1       | Command and response packet .....                     | 3         |
| 1.4.2       | Detail of packet fields .....                         | 4         |
| 1.4.3       | Response code .....                                   | 4         |
| 2           | Communication sequence .....                          | 5         |
| 2.1         | <b>Setting command</b> .....                          | <b>5</b>  |
| 2.2         | <b>Status request command</b> .....                   | <b>5</b>  |
| 3           | Command .....   | 6         |
| 3.1         | <b>Command overview</b> .....                         | <b>6</b>  |
| 3.2         | <b>System command</b> .....                           | <b>7</b>  |
| 3.2.1       | Reboot .....  | 7         |
| 3.2.2       | Get version information .....                         | 7         |
| 3.2.3       | Network address setting .....                         | 7         |
| 3.2.4       | Get network information .....                         | 7         |
| 3.2.5       | TCP keep-alive settings .....                         | 8         |
| 3.2.6       | Get TCP keep-alive information .....                  | 8         |
| 3.2.7       | Get model name .....                                  | 9         |
| 3.2.8       | Get serial number .....                               | 9         |
| 3.2.9       | Get system down factor .....                          | 10        |
| 3.2.10      | Factory reset .....                                   | 10        |
| 3.3         | <b>Pan/Tilt control</b> .....                         | <b>11</b> |
| 3.3.1       | Mount mode setting .....                              | 11        |
| 3.3.2       | Get mount mode .....                                  | 11        |
| 3.3.3       | Get maximum speed value .....                         | 12        |
| 3.3.4       | Get motor information .....                           | 12        |
| 3.3.5       | Speed (IR remote control) setting .....               | 13        |
| 3.3.6       | Get speed (IR remote control) .....                   | 13        |
| 3.3.7       | Control mode setting .....                            | 13        |
| 3.3.8       | Get control mode .....                                | 13        |
| 3.3.9       | Movement limit range (user limit) setting .....       | 14        |
| 3.3.10      | Get movement limit range (user limit) .....           | 14        |
| 3.3.11      | Speed button setting .....                            | 15        |
| 3.3.12      | Get speed button .....                                | 15        |
| 3.3.13      | Origin movement speed setting .....                   | 16        |
| 3.3.14      | Get origin movement speed .....                       | 16        |
| 3.3.15      | Trigger move .....                                    | 17        |
| 3.3.16      | Get motor/tally status .....                          | 18        |
| 3.3.17      | Trigger movement and get motor/tally status .....     | 19        |
| 3.3.18      | Origin moves .....                                    | 19        |
| 3.3.19      | Specified position move .....                         | 19        |
| 3.3.20      | User home position setting .....                      | 20        |
| 3.3.21      | Get user home position .....                          | 20        |
| 3.3.22      | Move user home position .....                         | 20        |
| 3.3.23      | Preset position setting .....                         | 21        |
| 3.3.24      | Get preset position .....                             | 21        |
| 3.3.25      | Move to preset position .....                         | 21        |
| 3.3.26      | LED setting .....                                     | 22        |
| 3.3.27      | Get LED .....   | 22        |
| Appendix A. | Initial value/fixed value .....                       | 23        |
| Appendix B. | Command example - basic operation .....               | 25        |
| 1.          | Get maximum speed number .....                        | 25        |
| 2.          | Pan move .....  | 26        |
| 3.          | Pan/Tilt move .....                                   | 27        |
| 4.          | Pan/Tilt stop .....                                   | 28        |
| 5.          | Pan/Tilt origin move .....                            | 29        |
| 6.          | Pan/Tilt move, Get status - Detail type command ..... | 30        |

# 1 External control protocol

## 1.1 Communication device

The PT-LAN51 (device) and an external control device (host) such as a PC can be connected via serial communication (RS-232C) or Ethernet.

- (\*) Do not control from both RS-232C and Ethernet at the same time.
- (\*) Do not make TCP connections to one device from multiple hosts.

## 1.2 Communication setting

Communication specifications of serial communication

| Baud rate | Data length | Stop Bit | Parity Bit | Flow |
|-----------|-------------|----------|------------|------|
| 38400bps  | 8 bits      | 1 bit    | No         | No   |


Communication specifications of Ethernet communication

When using for the first time, it is necessary to connect with serial communication and set the IP address.

| Default IP address | Default Subnet mask | Default Gateway | Port   |
|--------------------|---------------------|-----------------|--------|
| 192.168.1.100      | 255.255.255.0       | 192.168.1.254   | 0xD002 |

## 1.3 Communication protocol

The communication protocol between the device and the host is a master-slave method in which the device responds to host requests.



## 1.4 Packet format

The packet format sent and received between the host and device is independent of the communication medium. Data in each area is stored in Big Endian.

- (\*) For serial communication, send each communication data within 100msec.
- (\*) For Ethernet communication, send STX to BCC in one TCP/IP packet.

### 1.4.1 Command and response packet

Command packet

|     |     |     |      |     |       |       |      |     |     |
|-----|-----|-----|------|-----|-------|-------|------|-----|-----|
| STX | DIR | ADR | TYPE | LEN | CODE1 | CODE2 | DATA | EXT | BCC |
|-----|-----|-----|------|-----|-------|-------|------|-----|-----|

Command response packet

|     |
|-----|
| RES |
|-----|

Status request response packet

|     |     |     |      |     |       |       |      |     |     |
|-----|-----|-----|------|-----|-------|-------|------|-----|-----|
| STX | DIR | ADR | TYPE | LEN | CODE1 | CODE2 | DATA | EXT | BCC |
|-----|-----|-----|------|-----|-------|-------|------|-----|-----|

### 1.4.2 Detail of packet fields

| Name  | Length  | Bit   | Definition  |
|-------|---------|-------|---|
| STX   | 1byte   | -     | Packet starts code (fixed at 0x02)  |
| DIR   | 1byte   | -     | Packet direction code<br>0x80: Command<br>0x40: Response  |
| ADR   | 1byte   | -     | Device address number (fixed at 0x00)   |
| TYPE  | 1byte   | -     | Model code (fixed at 0x01)  |
| LEN   | 2byte   | -     | Byte length of transmission data (not including CODE1 and CODE2)  |
| CODE1 | 1byte   | [7]   | Command type<br>0: Setting command<br>1: Getting command  |
|       |         | [6:5] | Unused (fix at 0)   |
|       |         | [4]   | Switch location information<br>0: Pulse value<br>1: Angle value (Angle x 100 times value)<br>(* Valid only for command category = 0x05<Pan/Tilt>. Otherwise fixed at 0. |
|       |         | [3:0] | Command category<br>0x0: System commands<br>0x5: Pan/Tilt control   |
| CODE2 | 1byte   | -     | Command code  |
| DATA  | 0 - LEN | -     | Send data for data length<br>(This field does not exist if the data length is 0)  |
| ETX   | 1byte   | -     | Packet end code (fixed at 0x03)   |
| BCC   | 1byte   | -     | Check code (XOR value from STX to ETX)  |

| Name | Length | Definition       |
|------|--------|------------------|
| RES  | 1byte  | Command response |

### 1.4.3 Response code


| Name            | Value | Definition  |
|-----------------|-------|---|
| RES_ACK         | 0x20  | Success of receiving  |
| RES_NAK_RCV_TO  | 0x41  | Timeout error   |
| RES_NAK_BCC     | 0x42  | BCC error   |
| RES_NG_NO_CMD   | 0x81  | Unknown command   |
| RES_NG_INIT     | 0x82  | Before initialization   |
| RES_NG_STATE    | 0x83  | Impossible to receive<br>(In case equipment cannot execute command) |
| RES_NG_DATA_LEN | 0x84  | Incorrect data length   |
| RES_NG_PARA     | 0x85  | Incorrect parameter   |
| RES_NG_MOVE     | 0x86  | Failed in command movement  |

## 2 Communication sequence

There are two types of commands. The first is a command to set the main unit, and the second is a command to request the current state.


### 2.1 Setting command

The setting command returns only a 1-byte response code.



### 2.2 Status request command

A status request command returns a 1-byte response code, and then returns the requested response data.



### 3 Command

#### 3.1 Command overview

| Command Category   | CODE1   | CODE2       | Command Type   | Action                                      |
|--------------------|---|-------------|----------------|---|
| 0x00<br>(System)   | 0x00  | 0x00        | Setting        | Reboot                                      |
|                    |   | 0x02        |                | Network address setting                     |
|                    |   | 0x03        |                | TCP keep-alive setting                      |
|                    |   | 0x0F        |                | Factory reset                               |
|                    | 0x80  | 0x01        | Status request | Get version information                     |
|                    |   | 0x02        |                | Get network information                     |
|                    |   | 0x03        |                | Get TCP keep-alive information              |
|                    |   | 0x05        |                | Get model name                              |
|                    |   | 0x06        |                | Get serial number                           |
|                    |   | 0x0E        |                | Get system down factor                      |
| 0x05<br>(Pan/Tilt) | 0x05<br>(Pulse value),<br>0x15<br>(Angle value) | 0x01        | Setting        | Mount mode setting                          |
|                    |   | 0x04        |                | Speed (IR remote control) setting           |
|                    |   | 0x05        |                | Control mode setting                        |
|                    |   | 0x06        |                | Movement limit range (user limit) setting   |
|                    |   | 0x07        |                | Speed button setting                        |
|                    |   | 0x08        |                | Origin movement speed setting               |
|                    |   | 0x20        |                | Trigger move                                |
|                    |   | 0x21        |                | Trigger movement and get motor/tally status |
|                    |   | 0x22        |                | Origin moves                                |
|                    |   | 0x23        |                | Specified position move                     |
|                    |   | 0x24        |                | User home position setting                  |
|                    |   | 0x25        |                | Move user home position                     |
|                    |   | 0x26        |                | Preset position setting                     |
|                    |   | 0x27        |                | Move to preset position                     |
|                    | 0x28  | LED setting |                |   |
|                    | 0x85<br>(Pulse value),<br>0x95<br>(Angle value) | 0x01        | Status request | Get mount mode                              |
|                    |   | 0x02        |                | Get maximum speed value                     |
|                    |   | 0x03        |                | Get motor information                       |
|                    |   | 0x04        |                | Get speed (IR remote control)               |
|                    |   | 0x05        |                | Get control mode                            |
|                    |   | 0x06        |                | Get movement limit range (user limit)       |
|                    |   | 0x07        |                | Get speed button                            |
|                    |   | 0x08        |                | Get origin movement speed                   |
|                    |   | 0x20        |                | Get motor/tally status                      |
|                    |   | 0x24        |                | Get user home position                      |
|                    |   | 0x26        |                | Get preset position                         |
|                    |   | 0x28        |                | Get LED status                              |

## 3.2 System command

### 3.2.1 Reboot

Reboot PT-LAN51.

< Setting command >

| LEN | CODE1 | CODE2 | DATA |
|-----|-------|-------|------|
| 0   | 0x00  | 0x00  | -    |

### 3.2.2 Get version information

Get the version information of the firmware.

< Status request command >

| LEN | CODE1 | CODE2 | DATA |
|-----|-------|-------|------|
| 0   | 0x80  | 0x01  | -    |

< Response >

| LEN | CODE1 | CODE2 | DATA 1        | DATA 2             | DATA 3-4      |
|-----|-------|-------|---------------|--------------------|---------------|
| 4   | 0x80  | 0x01  | Major version | Reserved<br>(0x00) | Minor version |

### 3.2.3 Network address setting

Make Ethernet setting for the main unit.

This unit does not support DHCP. Please set a valid network address.

The setting will be reflected after a reboot.

< Setting command >

| LEN | CODE1 | CODE2 | DATA 1-4   | DATA 5-8    | DATA 9-12       |
|-----|-------|-------|------------|-------------|-----------------|
| 12  | 0x00  | 0x02  | IP address | Subnet mask | Default gateway |

### 3.2.4 Get network information

Get current Ethernet setting information.

< Status request command >

| LEN | CODE1 | CODE2 | DATA |
|-----|-------|-------|------|
| 0   | 0x80  | 0x02  | -    |

< Response >

| LEN | CODE1 | CODE2 | DATA 1-4   | DATA 5-8    | DATA 9-12       | DATA 13-18  | DATA 19-20                       |
|-----|-------|-------|------------|-------------|-----------------|-------------|----------------------------------|
| 20  | 0x80  | 0x02  | IP address | Subnet mask | Default gateway | MAC address | Port number<br>(Fixed<br>0xD002) |

### 3.2.5 TCP keep-alive setting

Set the TCP keep-alive function.

The setting will be reflected after a reboot.

When this function is enabled, if no data transmission/reception continues for <Time> period while TCP connection is established, TCP keep-alive packet will be sent and response packet or sequence data communication to the same packet will be sent for <Interval> wait duration. This "packet transmission + response wait" is repeated <Number of transmissions> times until a response is obtained. If the response is not finally obtained, the device closes the current TCP connection and returns to the state of waiting for connection establishment.

< Setting command >

| LEN | CODE1 | CODE2 | DATA 1         | DATA 2-3 | DATA 4-5 | DATA 6-7                |
|-----|-------|-------|----------------|----------|----------|-------------------------|
| 7   | 0x00  | 0x03  | Enable/Disable | Time     | Interval | Number of transmissions |

#### Enable/Disable

Enables (1) / Disables (0) the TCP keep-alive function.

If disable is selected, set dummy data (e.g., 0) to <Time>, <Interval> and < Number of transmissions>.

#### Time

Sets the time from the last data transmission/reception to the first TCP keep-alive packet.

The unit is seconds (\*). If 0 is specified, 1 is set.

#### Interval

Sets the time to wait for a Response to TCP keep-alive packets.

The unit is seconds (\*). If 0 is specified, 1 is set.

#### Number of transmissions

Set the number of "TCP keep alive packet transmission + wait for response".

If set to 0, closes the TCP connection without sending a TCP keep-alive packet <Time> after the last data was sent or received.

(\*) Due to the internal counter, a time lag may occur depending on the operating conditions.

### 3.2.6 Get TCP keep-alive information

Get the current TCP keepalive feature setting.

< Status request command >

| LEN | CODE1 | CODE2 | DATA |
|-----|-------|-------|------|
| 0   | 0x80  | 0x03  | -    |

< Response >

| LEN | CODE1 | CODE2 | DATA 1         | DATA 2-3 | DATA 4-5 | DATA 6-7                |
|-----|-------|-------|----------------|----------|----------|-------------------------|
| 7   | 0x80  | 0x03  | Enable/Disable | Time     | Interval | Number of transmissions |

#### Enable/Disable

#### Time

#### Interval

#### Number of transmissions

Same as 0x00\_0x03 command (TCP keep-alive setting)

### 3.2.7 Get model name

Get the model's name.

< Status request command >

| LEN | CODE1 | CODE2 | DATA |
|-----|-------|-------|------|
| 0   | 0x80  | 0x05  | -    |

< Response >

| LEN | CODE1 | CODE2 | DATA 1-8    | DATA 9-16    | DATA 17-24 |
|-----|-------|-------|-------------|--------------|------------|
| 24  | 0x80  | 0x05  | Series name | Model's name | Option     |

Series name

You can get the series name "PT" of this unit as a fixed value.

Model's name

You can get the model name "LAN51" of this unit as a fixed value.

Option

Used to identify derived models.

### 3.2.8 Get serial number

Get the serial number.

< Status request command >

| LEN | CODE1 | CODE2 | DATA |
|-----|-------|-------|------|
| 0   | 0x80  | 0x06  | -    |

< Response >

| LEN | CODE1 | CODE2 | DATA 1         | DATA 2-9      |
|-----|-------|-------|----------------|---------------|
| 9   | 0x80  | 0x06  | Reserved(0x00) | Serial number |

Serial number

Serial number (ASCII Character code)

### 3.2.9 Get system down factor

Get the current system down factor.

< Status request command >

| LEN | CODE1 | CODE2 | DATA |
|-----|-------|-------|------|
| 0   | 0x80  | 0x0E  | -    |

< Response >

| LEN | CODE1 | CODE2 | DATA 1               | DATA 2               |
|-----|-------|-------|----------------------|----------------------|
| 2   | 0x80  | 0x0E  | System down factor 1 | System down factor 2 |

#### System down factor

1: There is a system down factor

0: There is no system down factor (or the factor has already been resolved)

| System down factor 1 | Definition                             |
|----------------------|--|
| [7-2]                | (Unused)                               |
| [1]                  | Abnormal access to non-volatile memory |
| [0]                  | Abnormal temperature                   |

| System down factor 2 | Definition                  |
|----------------------|-----------------------------|
| [7]                  | Pan/Tilt emergency stop     |
| [6]                  | Power failure (DC-OUT)      |
| [5]                  | Power failure (Power Input) |
| [4]                  | PoE class fault             |
| [3-0]                | (Unused)                    |

### 3.2.10 Factory reset

Initializes the non-volatile memory that retains user settings and restores the factory defaults.

After initialization, the device will automatically restart.

< Setting command >

| LEN        | CODE1 | CODE2 | DATA |
|------------|-------|-------|------|
| 0 or 1 (*) | 0x00  | 0x0F  | Mode |

(\*) Initialize all items without DATA (Mode) if LEN=0

#### Mode

| DATA  | Definition                                       |
|-------|--|
| 0x10  | Initialize settings other than Ethernet settings |
| Other | Initialize all items                             |

### 3.3 Pan/Tilt control

Command for Pan/Tilt head.

CODE1 selects whether to process setting/getting and position information with pulse values or angle values.

| CODE1 | Set | Get | Pulse | Angle | Definition  |
|-------|-----|-----|-------|-------|---|
| 0x05  | ✓   | -   | ✓     | -     | Setting command. Position information is pulse value.                             |
| 0x85  | -   | ✓   | ✓     | -     | Getting command. Position information is pulse value.                             |
| 0x15  | ✓   | -   | -     | ✓     | Setting command. Position information is an angle value (angle x 100 times value) |
| 0x95  | -   | ✓   | -     | ✓     | Getting command. Position information is an angle value (angle x 100 times value) |

Angle values can be calculated from pulse values.

Angle value = pulse value \* step angle / gear ratio

The step angle and gear ratio can be obtained with the 0x85\_0x03 command (Get motor information).

#### 3.3.1 Mount mode setting

Sets the Pan/Tilt installation status.

< Setting command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 1   | 0x05, 0x15 | 0x01  | Mode |

Mode

| Bit   | Name              | Definition   |
|-------|-------------------|--|
| [7:3] | -                 | Unused (Fixed at 0)  |
| [2]   | Tilt reverse mode | This bit is valid only when "Mount mode" is normal (0).<br>0: Normal<br>1: Reverse, tilt works in the opposite direction |
| [1]   | pan reverse mode  | This bit is valid only when "Mount mode" is normal (0).<br>0: Normal<br>1: Reverse, pan works in the opposite direction  |
| [0]   | Mount mode        | 0: Normal<br>1: Ceiling mounted; Pan/Tilt operates in the opposite direction   |

#### 3.3.2 Get mount mode

Get the Pan/Tilt installation status.

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x01  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 1   | 0x85, 0x95 | 0x01  | Mode |

Mode

| Bit   | Name              | Definition  |
|-------|-------------------|---|
| [7:5] | -                 | (Unused)  |
| [4]   | Stage mode        | 0: Upper, set the stage up<br>1: Lower, set the stage down<br>(* This setting is done with the DIP switch on the main unit. |
| [3]   | -                 | (Unused)  |
| [2]   | Tilt reverse mode | This bit is valid only when "Mount mode" is normal (0).<br>0: Normal<br>1: Reverse, tilt works in the opposite direction    |
| [1]   | pan reverse mode  | This bit is valid only when "Mount mode" is normal (0).<br>0: Normal<br>1: Reverse, pan works in the opposite direction     |
| [0]   | Mount mode        | 0: Normal<br>1: Ceiling mounted; Pan/Tilt operates in the opposite direction  |

### 3.3.3 Get maximum speed value

Get the maximum pan/tilt speed value.

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x02  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA 1              |
|-----|------------|-------|---------------------|
| 1   | 0x85, 0x95 | 0x02  | Maximum speed value |

Maximum speed value

Maximum speed value (Common Pan/Tilt)

### 3.3.4 Get motor information

Get information of each motor such as operating range (limit position) of each axis, motor step angle, gear ratio, etc.

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x03  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA 1-2           | DATA 3-4           | DATA 5-6            | DATA 7-8            |
|-----|------------|-------|--------------------|--------------------|---------------------|---------------------|
| 16  | 0x85, 0x95 | 0x03  | Pan<br>step angle  | Pan<br>gear ratio  | Pan<br>limit(right) | Pan<br>limit(left)  |
|     |            |       | DATA 9-10          | DATA 11-12         | DATA 13-14          | DATA 15-16          |
|     |            |       | Tilt<br>step angle | Tilt<br>gear ratio | Tilt<br>limit(up)   | Tilt<br>limit(down) |

Pan step angle

Tilt step angle

It is the value obtained by multiplying the step angle of the motor by 1000.

Pan gear ratio

Tilt gear ratio

It is the value of the gear ratio of the mechanism.

Pan limit(right)

Pan limit(left)

It is the limit position value that Pan can operate (16bits signed integer).

Tilt limit (up)

Tilt limit (down)

It is the limit position value that Tilt can operate (16bits signed integer)

### 3.3.5 Speed (IR remote control) setting

Sets the speed at which the IR remote control operates.

< Setting command >

| LEN | CODE1      | CODE2 | DATA 1    | DATA 2     |
|-----|------------|-------|-----------|------------|
| 2   | 0x05, 0x15 | 0x04  | Pan speed | Tilt speed |

Pan speed

Tilt speed

Operation speed: maximum speed value (highest speed) ~ 1 (lowest speed)

Get the maximum speed value that can be set with the 0x85\_0x02 command (Get maximum speed value).

### 3.3.6 Get speed (IR remote control)

Get the operation speed that works with the IR remote control.

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x04  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA 1    | DATA 2     |
|-----|------------|-------|-----------|------------|
| 2   | 0x85, 0x95 | 0x04  | Pan speed | Tilt speed |

Pan speed

Tilt speed

Operation speed

### 3.3.7 Control mode setting

Sets the Pan/Tilt control mode.

< Setting command >

| LEN | CODE1      | CODE2 | DATA 1       |
|-----|------------|-------|--------------|
| 1   | 0x05, 0x15 | 0x05  | Control mode |

Control mode

| Bit   | Name                | Definition   |
|-------|---------------------|--|
| [7:5] | -                   | Unused (Fixed at 0)  |
| [4]   | Smart position move | Adjust the speed of Pan/Tilt to the position specified by the position movement command, move in a straight line as much as possible (0: off, 1: on) |
| [3:0] | -                   | Unused (Fixed at 0)  |

### 3.3.8 Get control mode

Gets the Pan/Tilt control mode.

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x05  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA 1       |
|-----|------------|-------|--------------|
| 1   | 0x85, 0x95 | 0x05  | Control mode |

Control mode

Same as 0x05\_0x05 command (Control mode setting).

### 3.3.9 Movement limit range (user limit) setting

Sets the operating range of Pan/Tilt.

< Setting command >

| LEN | CODE1      | CODE2 | DATA 1 | DATA 2-3        | DATA 4-5       | DATA 6-7      | DATA 8-9        |
|-----|------------|-------|--------|-----------------|----------------|---------------|-----------------|
| 9   | 0x05, 0x15 | 0x06  | Mode   | Pan right (Max) | Pan left (Min) | Tilt up (Max) | Tilt down (Min) |

Mode

| Bit   | Name      | Definition  |
|-------|-----------|---|
| [7:4] | Tilt Mode | 0x0: Reset (the setting is canceled, and the unit operates within the limit range)<br>0x1: Setting<br>0x2 to 0xF: No change |
| [3:0] | Pan Mode  | 0x0: Reset (the setting is canceled, and the unit operates within the limit range)<br>0x1: Setting<br>0x2 to 0xF: No change |

If reset is selected at the Pan/Tilt mode, set dummy data (e.g., 0) to the reset parts of <Pan right (Max)>, <Pan left (Min)>, <Tilt up (Max)> and <Tilt down (Min)>.

Pan right(max) limit

Pan left(min) limit

Tilt up(max) limit

Tilt down(min) limit

Specify the operating range. Set the configurable range within the limits of the 0x05\_0x03 command (Get motor information). It is recommended to include the origin in the setting range. Regardless of this setting range, it will move to the origin-by-origin movement request. (16bits signed integer)

### 3.3.10 Get movement limit range (user limit)

Get the Pan/Tilt operating range.

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x06  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA 1 | DATA 2-3        | DATA 4-5       | DATA 6-7      | DATA 8-9        |
|-----|------------|-------|--------|-----------------|----------------|---------------|-----------------|
| 9   | 0x85, 0x95 | 0x06  | Mode   | Pan right (Max) | Pan left (Min) | Tilt up (Max) | Tilt down (Min) |

Mode

| Bit   | Name      | Definition                       |
|-------|-----------|----------------------------------|
| [7:4] | Tilt Mode | 0x0: Not set<br>0x1: Already set |
| [3:0] | Pan Mode  | 0x0: Not set<br>0x1: Already set |

Pan right(max) limit

Pan left(min) limit

Tilt up(max) limit

Tilt down(min) limit

If it has already been set, the operating range can be acquired. If not set, the same value as each limit of the 0x05\_0x03 command (Get motor information) is returned. (16bits signed integer)

### 3.3.11 Speed button setting

Sets the speed of the speed button on the IR remote control.

< Setting command >

| LEN | CODE1      | CODE2 | DATA 1 | DATA 2  | DATA 3  | DATA 4  |
|-----|------------|-------|--------|---------|---------|---------|
| 4   | 0x05, 0x15 | 0x07  | Mode   | Speed 1 | Speed 2 | Speed 3 |

Mode

| Bit   | Name  | Definition   |
|-------|-------|--|
| [7:5] | -     | Unused (Fixed at 0)                                |
| [4]   | Mode  | 0: Initialize (set to default value)<br>1: Setting |
| [3:1] | -     | Unused (Fixed at 0)                                |
| [0]   | Motor | 0: Pan<br>1: Tilt                                  |

If initialize is selected at the mode, set dummy data (e.g., 0) to <speed 1>, <speed 2>, and <speed 3>.

Speed 1-3

Setting speed for each button: Maximum speed value (highest speed) ~ 1 (lowest speed)

Get the maximum speed value that can be set with the 0x85\_0x02 command (Get maximum speed value).

### 3.3.12 Get speed button

Get the information of the speed button of the IR remote control.

< Status request command >

| LEN | CODE1      | CODE2 | DATA  |
|-----|------------|-------|-------|
| 1   | 0x85, 0x95 | 0x07  | Motor |

Motor

Motor (axis) selection

| Bit   | Name  | Definition        |
|-------|-------|-------------------|
| [7:1] | -     | (Unused)          |
| [0]   | Motor | 0: Pan<br>1: Tilt |

< Response >

| LEN | CODE1      | CODE2 | DATA 1  | DATA 2  | DATA 3  |
|-----|------------|-------|---------|---------|---------|
| 3   | 0x85, 0x95 | 0x07  | Speed 1 | Speed 2 | Speed 3 |

Speed 1-3

Same as 0x05\_0x07 command (Speed button setting).

### 3.3.13 Origin movement speed setting

Set the movement speed to the origin position.

< Setting command >

| LEN | CODE1      | CODE2 | DATA 1    | DATA 2     |
|-----|------------|-------|-----------|------------|
| 2   | 0x05, 0x15 | 0x08  | Pan speed | Tilt speed |

Pan speed

Tilt speed

Movement speed to origin position: Maximum speed value (highest speed) ~ 1 (lowest speed)

Get the maximum speed value that can be set with the 0x85\_0x02 command (Get maximum speed value).

### 3.3.14 Get origin movement speed

Get the movement speed to the origin position.

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x08  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA 1    | DATA 2     |
|-----|------------|-------|-----------|------------|
| 2   | 0x85, 0x95 | 0x08  | Pan speed | Tilt speed |

Pan speed

Tilt speed

It is the same as the 0x05\_0x08 command (Origin movement speed setting).

### 3.3.15 Trigger move

Perform trigger action.

< Setting command >

| LEN | CODE1      | CODE2 | DATA 1 | DATA 2    | DATA 3     |
|-----|------------|-------|--------|-----------|------------|
| 3   | 0x05, 0x15 | 0x20  | Mode   | Pan speed | Tilt speed |

#### Mode

| Bit   | Name       | Definition  |
|-------|------------|---|
| [7]   | -          | Unused (Fixed at 0)   |
| [6]   | Pan valid  | 0: Pan specification invalid (Pan motor does not work)<br>1: Pan specification valid    |
| [5:4] | Pan mode   | 0: Stop<br>1: Move left<br>2: Move right<br>3: Move to origin                           |
| [3]   | -          | Unused (Fixed at 0)   |
| [2]   | Tilt valid | 0: Tilt specification invalid (Tilt motor does not work)<br>1: Tilt specification valid |
| [1:0] | Tilt mode  | 0: Stop<br>1: Move up<br>2: Move down<br>3: Move to origin                              |

If invalid is selected at the pan/tilt valid, set dummy data (e.g., 0) to the disabled parts of <Pan mode>, <Tilt mode>, <Pan speed> and <Tilt speed>.

#### Pan speed

#### Tilt speed

Operation speed: maximum speed value (highest speed) ~ 1 (lowest speed)

Get the maximum speed value that can be set with the 0x85\_0x02 command (Get maximum speed value).

### 3.3.16 Get motor/tally status

Get the Pan/Tilt status and tally lamp status.

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x20  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA 1 | DATA 2-3     | DATA 4-5      |
|-----|------------|-------|--------|--------------|---------------|
| 5   | 0x85, 0x95 | 0x20  | Status | Pan position | Tilt position |

Status

| Bit   | Name  | Definition   |
|-------|-------|--|
| [7]   | -     | (Unused)   |
| [6]   | Tally | 0: Off<br>1: On  |
| [5:4] | Pan   | 0: Initializing (move commands cannot be accepted)<br>1: Initialization completed or stopped<br>2: Moving<br>3: Limit position reached |
| [3:2] | Tilt  | 0: Initializing (move commands cannot be accepted)<br>1: Initialization completed or stopped<br>2: Moving<br>3: Limit position reached |
| [1:0] | -     | (Unused)   |

Pan position

Pan current position

Tilt position

Tilt current position

### 3.3.17 Trigger movement and get motor/tally status

This command performs trigger operation and motor/tally status acquisition at the same time.

< Setting & Status request command >

The communication sequence is the same as "Status request command".

| LEN | CODE1      | CODE2 | DATA 1        | DATA 2    | DATA 3     |
|-----|------------|-------|---------------|-----------|------------|
| 3   | 0x05, 0x15 | 0x21  | Pan/Tilt mode | Pan speed | Tilt speed |

Pan/Tilt Mode

Pan speed

Tilt speed

Same as 0x05\_0x20 command (Trigger move)

< Response >

| LEN | CODE1      | CODE2 | DATA 1 | DATA 2-3     | DATA 4-5      |
|-----|------------|-------|--------|--------------|---------------|
| 5   | 0x05, 0x15 | 0x21  | Status | Pan position | Tilt position |

Status

Pan position

Tilt position

Same as 0x85\_0x20 command (Get motor/tally status)

### 3.3.18 Origin moves

Move to the origin position.

< Setting command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x05, 0x15 | 0x22  | -    |

### 3.3.19 Specified position move

Move to the specified position.

< Setting command >

| LEN | CODE1      | CODE2 | DATA 1 | DATA 2 | DATA 3-4     | DATA 5-6      |
|-----|------------|-------|--------|--------|--------------|---------------|
| 6   | 0x05, 0x15 | 0x23  | Mode   | Speed  | Pan position | Tilt position |

Mode

| Bit   | Name       | Definition  |
|-------|------------|---|
| [7:2] | -          | Unused (Fixed at 0)   |
| [1]   | Tilt valid | 0: Tilt specification invalid (Tilt motor does not work)<br>1: Tilt specification valid |
| [0]   | Pan valid  | 0: Pan specification invalid (Pan motor does not work)<br>1: Pan specification valid    |

If invalid is selected at the pan/tilt valid, set dummy data (e.g., 0) to the disabled parts of <Pan position> and <Tilt position>

Speed

Operation speed: maximum speed value (highest speed) ~ 1 (lowest speed)

Get the maximum speed value that can be set with the 0x85\_0x02 command (Get maximum speed value).

Pan position

Tilt position

Same as 0x85\_0x20 command (Get motor/tally status)

### 3.3.20 User home position setting

Set or delete the user home position.

< Setting command >

| LEN    | CODE1      | CODE2 | DATA 1 | DATA 2-3     | DATA 4-5      |
|--------|------------|-------|--------|--------------|---------------|
| 1 or 5 | 0x05, 0x15 | 0x24  | Mode   | Pan position | Tilt position |

Mode (\*1)

| Name | Definition  |
|------|---|
| Mode | 0: Delete<br>Delete user home position information                                      |
|      | 1: Register current position<br>Register current position as user home position         |
|      | 2: Specified position setting<br>Sets the specified position as the user home position. |

If delete is selected at the mode, set dummy data (e.g., 0) to <Pan position> and <Tilt position>.

Pan position

Pan position (Valid when "Mode" = 2) (\*)

Tilt position

Tilt position (Valid when "Mode" = 2) (\*)

(\*) When Mode=0,1, Pan/Tilt position can be omitted with LEN=1.

If Mode=2, be sure to set LEN=5.

Set the setting position within the range obtained by the 0x85\_0x03 command (Get motor information).

### 3.3.21 Get user home position

Get user home position setting information.

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x24  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA 1 | DATA 2-3     | DATA 4-5      |
|-----|------------|-------|--------|--------------|---------------|
| 5   | 0x85, 0x95 | 0x24  | Status | Pan position | Tilt position |

Status

User home position setting state (0: not set, 1: set)

Pan position

Pan position (Valid when "Status" = 1)

Tilt position

Tilt position (Valid when "Status" = 1)

### 3.3.22 Move user home position

Move to user home position.

It will not work if the user home position is not set.

< Setting command >

| LEN        | CODE1      | CODE2 | DATA 1 |
|------------|------------|-------|--------|
| 0 or 1 (*) | 0x05, 0x15 | 0x25  | Speed  |

(\*) If LEN=0, it will operate at the speed specified on the main unit side (same speed as origin movement)

Speed

Operation speed: maximum speed value (highest speed) ~ 1 (lowest speed)

Get the maximum speed value that can be set with the 0x85\_02 command (Get maximum speed value).

### 3.3.23 Preset position setting

Sets the current Pan/Tilt position as a preset position.

< Setting command >

| LEN | CODE1      | CODE2 | DATA 1        |
|-----|------------|-------|---------------|
| 1   | 0x05, 0x15 | 0x26  | Preset number |

Preset number

15 presets can be set (1-15)

### 3.3.24 Get preset position

Get preset position information.

< Status request command >

| LEN | CODE1      | CODE2 | DATA 1        |
|-----|------------|-------|---------------|
| 1   | 0x85, 0x95 | 0x26  | Preset number |

Preset number

Same as 0x05\_0x26 command (Preset position setting).

< Response >

| LEN | CODE1      | CODE2 | DATA 1-2     | DATA 3-4      |
|-----|------------|-------|--------------|---------------|
| 4   | 0x85, 0x95 | 0x26  | Pan position | Tilt position |

Pan position

Pan preset position

Tilt position

Tilt preset position

### 3.3.25 Move to preset position

Move to preset position.

< Setting command >

| LEN | CODE1      | CODE2 | DATA 1        | DATA 2 |
|-----|------------|-------|---------------|--------|
| 2   | 0x05, 0x15 | 0x27  | Preset number | Speed  |

Preset number

Same as 0x05\_0x26 command (Preset position setting).

Speed

Operation speed: maximum speed value (highest speed) ~ 1 (lowest speed)

Get the maximum speed value that can be set with the 0x85\_02 command (Get maximum speed value).

### 3.3.26 LED setting

Sets the LED (Tally).

< Setting command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 1   | 0x05, 0x15 | 0x28  | LED  |

LED

| Bit   | Name  | Definition              |
|-------|-------|-------------------------|
| [7:1] | -     | Unused (Fixed at 0)     |
| [0]   | Tally | Tally ( 0: Off, 1: On ) |

Tally light turns to "0: Off" with power off/on.

### 3.3.27 Get LED status

Gets the status of the LED (Tally).

< Status request command >

| LEN | CODE1      | CODE2 | DATA |
|-----|------------|-------|------|
| 0   | 0x85, 0x95 | 0x28  | -    |

< Response >

| LEN | CODE1      | CODE2 | DATA 1 |
|-----|------------|-------|--------|
| 1   | 0x85, 0x95 | 0x28  | LED    |

LED

Same as 0x05\_0x28 command (LED setting).

## Appendix A. Initial value/fixed value

### ■ Initial value list

| Command Category | CODE2              | Command                            | Item                 | Value                 |
|------------------|--------------------|------------------------------------|----------------------|-----------------------|
| 0x00             | 0x02               | Network address                    | IP address           | 192.168.1.100         |
|                  |                    |                                    | Subnet mask          | 255.255.255.0         |
|                  |                    |                                    | Default gateway      | 192.168.1.254         |
|                  | 0x03               | TCP keep-alive                     | Enable/Disable       | Disable               |
|                  |                    |                                    | Time                 | 7200 (second = 2hour) |
|                  |                    |                                    | Interval             | 75 (second)           |
| 0x05             | 0x01               | Mount mode                         | Mount mode           | Normal                |
|                  |                    |                                    | Pan reverse mode     | Normal                |
|                  |                    |                                    | Tilt reverse mode    | Normal                |
|                  | 0x04               | Speed (IR remote control)          | Pan speed            | 106                   |
|                  |                    |                                    | Tilt speed           | 106                   |
|                  | 0x05               | Control mode                       | Smart position move  | On                    |
|                  | 0x06               | Movement limit range (User limit)  | Pan right            | Not set               |
|                  |                    |                                    | Pan left             | Not set               |
|                  |                    |                                    | Tilt up              | 2500 (pulse) (*)      |
|                  |                    |                                    | Tilt down            | -2500 (pulse) (*)     |
|                  | 0x07               | Speed button                       | Speed 1 (Pan & Tilt) | 147                   |
|                  |                    |                                    | Speed2 (Pan & Tilt)  | 106                   |
|                  |                    |                                    | Speed3 (Pan & Tilt)  | 50                    |
|                  | 0x08               | Origin movement speed              | Pan speed            | 134                   |
|                  |                    |                                    | Tilt speed           | 78                    |
| 0x24             | User home position | Pan position                       | Not set              |                       |
|                  |                    | Tilt position                      | Not set              |                       |
| 0x26             | Preset position    | Pan position (Preset number 1-15)  | 0                    |                       |
|                  |                    | Tilt position (Preset number 1-15) | 0                    |                       |
| 0x28             | LED                | Tally                              | Off                  |                       |

(\*) Set during a factory reset. When reset by the movement restriction range Setting command, it becomes "not set".

### ■ Fixed value list

| Command Category | CODE2             | Command             | Item             | Value          |
|------------------|-------------------|---------------------|------------------|----------------|
| 0x05             | 0x02              | Maximum speed value | -                | 147            |
|                  | 0x03              | Motor information   | Pan step angle   | 1800 (pulse)   |
|                  |                   |                     | Pan gear ratio   | 150            |
|                  |                   |                     | Pan limit(right) | 14300 (pulse)  |
|                  |                   |                     | Pan limit (left) | -14300 (pulse) |
|                  |                   |                     | Tilt step angle  | 1800 (pulse)   |
|                  |                   |                     | Tilt gear ratio  | 150            |
|                  |                   |                     | Tilt limit (up)  | 14500 (pulse)  |
|                  | Tilt limit (down) | -14500 (pulse)      |                  |                |

■ Speed setting and rotation speed (excerpt)

| Speed setting | Rotation speed (angle°/sec) |
|---------------|-----------------------------|
| 147           | 50.0175                     |
| 134           | 45.3375                     |
| 120           | 40.2975                     |
| 106           | 35.2575                     |
| 92            | 30.2175                     |
| 78            | 25.1775                     |
| 64            | 20.1375                     |
| 50            | 15.0975                     |
| 43            | 12.5775                     |
| 36            | 10.0575                     |
| 29            | 7.5375                      |
| 25            | 6.0975                      |
| 17            | 3.2175                      |
| 13            | 1.7775                      |
| 7             | 0.36                        |

## Appendix B. Command example - basic operation

### 1. Get maximum speed number

First, get the maximum speed number of the main unit. The speed value may vary depending on the settings, so be sure to get it.

- (CODE1:0x85, CODE2:0x02) Get maximum speed number
  - No command data

Command packet (Host -> PT-LAN51)

| STX  | DIR  | ADR  | TYPE | LEN1 | LEN2 | CODE1 | CODE2 | ETX  | BCC  |
|------|------|------|------|------|------|-------|-------|------|------|
| 0x02 | 0x80 | 0x00 | 0x01 | 0x00 | 0x00 | 0x05  | 0x02  | 0x03 | 0x87 |

BCC = 0x02^0x80^0x00^0x01^0x00^0x00^0x05^0x02^0x03=0x87

Response code (PT-LAN51 -> Host)

| RES  |
|------|
| 0x20 |

0x20 = RES\_ACK: Successful receive

Response packet (PT-LAN51 -> Host)

| STX  | DIR  | ADR  | TYPE | LEN1 | LEN2 | CODE1 | CODE2 | DATA1 | ETX  | BCC  |
|------|------|------|------|------|------|-------|-------|-------|------|------|
| 0x02 | 0x40 | 0x00 | 0x01 | 0x00 | 0x02 | 0x05  | 0x02  | 0x93  | 0x03 | 0xD6 |

BCC = 0x02^0x40^0x00^0x01^0x00^0x02^0x05^0x02^0x93^0x03=0xD6

DATA1:Pan/Tilt max speed= 0x93 = 147 This value will be the maximum speed value.

## 2. Pan move

- (CODE1:0x05, CODE2:0x20) Trigger move
  - Pan (Enable, right, speed=100)

### DATA1

Pan/Tilt Mode = 0x60

| Bit   | Name       | Value    | Definition  |
|-------|------------|----------|---|
| [7]   | -          | 0-----   | 0: (Unused)   |
| [6]   | Pan valid  | -1-----  | 1: Pan specification valid                              |
| [5:4] | Pan Mode   | --10---- | 2: Move right   |
| [3]   | -          | ----0--- | 0: (Unused)   |
| [2]   | Tilt valid | ----0--  | 0: Tilt specification invalid                           |
| [1:0] | Tilt Mode  | -----00  | 0: Stop (Ignored because tilt specification is invalid) |

### DATA2

Pan Speed = 0x64 (=100)

### DATA3

Tilt Speed = 0x00 (=0)

Command packet (Host -> PT-LAN51)

| STX  | DIR  | ADR  | TYPE | LEN1 | LEN2 | CODE1 | CODE2 | DATA1 | DATA2 | DATA3 |
|------|------|------|------|------|------|-------|-------|-------|-------|-------|
| 0x02 | 0x80 | 0x00 | 0x01 | 0x00 | 0x03 | 0x05  | 0x20  | 0x60  | 0x64  | 0x00  |

| ETX  | BCC  |
|------|------|
| 0x03 | 0xA2 |

BCC = 0x02^0x80^0x00^0x01^0x00^0x03^0x05^0x20^0x60^0x64^0x00^0x03=0xA2

Response (PT-LAN51 -> Host)

| RES  |
|------|
| 0x20 |

0x20 = RES\_ACK: Successful receive

### 3. Pan/Tilt move

- (CODE1:0x05, CODE2:0x20) Trigger move
  - Pan (Enable, left, speed=147)
  - Tilt (Enable, down, speed=100)
  - No get status

#### DATA1

Pan/Tilt Mode = 0x56

| Bit   | Name       | Value    | Definition                  |
|-------|------------|----------|-----------------------------|
| [7]   | -          | 0-----   | 0: (Unused)                 |
| [6]   | Pan valid  | -1-----  | 1: Pan specification valid  |
| [5:4] | Pan Mode   | --01---- | 1: Move left                |
| [3]   | -          | ----0--- | 0: (Unused)                 |
| [2]   | Tilt valid | ----1--  | 1: Tilt specification valid |
| [1:0] | Tilt Mode  | -----10  | 2: Move down                |

#### DATA2

Pan Speed = 0x93 (=147)

#### DATA3

Tilt Speed = 0x64 (=100)

#### Command packet (Host -> PT-LAN51)

| STX  | DIR  | ADR  | TYPE | LEN1 | LEN2 | CODE1 | CODE2 | DATA1 | DATA2 | DATA3 |
|------|------|------|------|------|------|-------|-------|-------|-------|-------|
| 0x02 | 0x80 | 0x00 | 0x01 | 0x00 | 0x03 | 0x05  | 0x20  | 0x56  | 0x93  | 0x64  |

| ETX  | BCC  |
|------|------|
| 0x03 | 0x07 |

BCC = 0x02^0x80^0x00^0x01^0x00^0x03^0x05^0x20^0x56^0x93^0x64^0x03=0x07

#### Response (PT-LAN51 -> Host)

| RES  |
|------|
| 0x20 |

0x20 = RES\_ACK: Successful receive

#### 4. Pan/Tilt stop

- (CODE1:0x05, CODE2:0x20) Trigger move
  - Pan (Enable, stop)
  - Tilt (Enable, stop)

##### DATA1

Pan/Tilt Mode = 0x44

| Bit   | Name       | Value    | Definition                  |
|-------|------------|----------|-----------------------------|
| [7]   | -          | 0-----   | 0: (Unused)                 |
| [6]   | Pan valid  | -1-----  | 1: Pan specification valid  |
| [5:4] | Pan Mode   | --00---- | 0: Stop                     |
| [3]   | -          | ----0--- | 0: (Unused)                 |
| [2]   | Tilt valid | ----1--  | 1: Tilt specification valid |
| [1:0] | Tilt ode   | -----00  | 0: Stop                     |

##### DATA2

Pan Speed = 0x00

##### DATA3

Tilt Speed = 0x00

Command packet (Host -> PT-LAN51)

| STX  | DIR  | ADR  | TYPE | LEN1 | LEN2 | CODE1 | CODE2 | DATA1 | DATA2 | DATA3 |
|------|------|------|------|------|------|-------|-------|-------|-------|-------|
| 0x02 | 0x80 | 0x00 | 0x01 | 0x00 | 0x03 | 0x05  | 0x20  | 0x44  | 0x00  | 0x00  |

| ETX  | BCC  |
|------|------|
| 0x03 | 0xE2 |

BCC = 0x02^0x80^0x00^0x01^0x00^0x03^0x05^0x20^0x44^0x00^0x00^0x03=0xE2

Response (PT-LAN51 -> Host)

| RES  |
|------|
| 0x20 |

0x20 = RES\_ACK: Successful receive

## 5. Pan/Tilt origin move

- (CODE1:0x05, CODE2:0x20) Trigger move
  - Pan (Enable, move to origin)
  - Tilt (Enable, move to origin)

### DATA1

Pan/Tilt Mode = 0x77

| Bit   | Name       | Value    | Definition                  |
|-------|------------|----------|-----------------------------|
| [7]   | -          | 0-----   | 0: (Unused)                 |
| [6]   | Pan valid  | -1-----  | 1: Pan specification valid  |
| [5:4] | Pan Mode   | --11---- | 3: Move to origin           |
| [3]   | -          | ----0--- | 0: (Unused)                 |
| [2]   | Tilt valid | ----1--  | 1: Tilt specification valid |
| [1:0] | Tilt Mode  | -----11  | 3: Move to origin           |

### DATA2

Pan Speed = 0x00

### DATA3

Tilt Speed = 0x00

Command packet (Host -> PT-LAN51)

| STX  | DIR  | ADR  | TYPE | LEN1 | LEN2 | CODE1 | CODE2 | DATA1 | DATA2 | DATA3 |
|------|------|------|------|------|------|-------|-------|-------|-------|-------|
| 0x02 | 0x80 | 0x00 | 0x01 | 0x00 | 0x03 | 0x05  | 0x20  | 0x77  | 0x00  | 0x00  |

| ETX  | BCC  |
|------|------|
| 0x03 | 0xD1 |

BCC = 0x02^0x80^0x00^0x01^0x00^0x03^0x05^0x20^0x77^0x00^0x00^0x03=0xD1

Response (PT-LAN51 -> Host)

| RES  |
|------|
| 0x20 |

0x20 = RES\_ACK: Successful receive

## 6. Pan/Tilt move, Get status - Detail type command

- (CODE1:0x85, CODE2:0x20) Get motor/tally status
  - No command data

Command packet (Host -> PT-LAN51)

| STX  | DIR  | ADR  | TYPE | LEN1 | LEN2 | CODE1 | CODE2 | ETX  | BCC  |
|------|------|------|------|------|------|-------|-------|------|------|
| 0x02 | 0x80 | 0x00 | 0x01 | 0x00 | 0x00 | 0x85  | 0x20  | 0x03 | 0x25 |

BCC = 0x02^0x80^0x00^0x01^0x00^0x00^0x85^0x20^0x03=0x25

Response (PT-LAN51 -> Host)

| RES  |
|------|
| 0x20 |

0x20 = RES\_ACK: Successful receive

Response packet (PT-LAN51 -> Host)

| STX  | DIR  | ADR  | TYPE | LEN1 | LEN2 | CODE1 | CODE2 |
|------|------|------|------|------|------|-------|-------|
| 0x02 | 0x40 | 0x00 | 0x01 | 0x00 | 0x05 | 0x85  | 0x20  |

| DATA1 | DATA2-3 | DATA4-5 | EXT  | BCC  |
|-------|---------|---------|------|------|
| 0x28  | 0x3A    | 0x98    | 0xEC | 0x78 |

BCC = 0x02^0x40^0x00^0x01^0x00^0x05^0x85^0x20^0x28^0x3A^0x98^0xEC^0x78^0x03=0xFE

DATA1

Pan position = 0x28

| Bit   | Name  | Value    | Definition  |
|-------|-------|----------|-------------|
| [7]   | -     | 0-----   | 0: (Unused) |
| [6]   | Tally | -0-----  | 0: Off      |
| [5:4] | Pan   | --10---- | 2: Moving   |
| [3:2] | Tilt  | ----10-- | 2: Moving   |
| [1:0] | -     | -----00  | 0: (Unused) |

DATA2-3

Pan position = 0x3A98 = 15000

DATA4-5

Tilt position = 0xEC78 = -5000

(CODE1:0x84, CODE2:0xC3) The rotation angle can be calculated from the gear ratio and step angle obtained by motor information.

Pan step angle = 1800 => 1.8°

Pan gear ratio = 150

Pan position = 15000

$$15000 * 1.8 / 150 = 180^\circ$$

Tilt step angle = 1800 => 1.8°

Tilt gear ratio = 150

Tilt position = -5000

$$-5000 * 1.8 / 150 = -60^\circ$$



**EIZO Corporation**

[www.eizoglobal.com](http://www.eizoglobal.com)

Copyright © 2023 EIZO Corporation. All rights reserved.

00N0N439AZ  
UM-ECCS-PT-LAN51

1st Edition - August, 2023