



EIZO Releases FlexScan L352T-C 15-inch Touch Panel LCD Monitor



Matto, Japan, December 12, 2003 – Eizo Nanao Corporation today introduced the FlexScan L352T-C, a 15-inch (38 cm) touch panel LCD monitor utilizing analog capacitive technology and accepting finger and dedicated pen touch input. The FlexScan L352T-C's sturdy construction and long touch life yield long-term reliable operation for kiosks, factories, point-of-sale, and reception areas. It is also TÜV/GM¹ certified for use in medical environments including operating rooms.

The FlexScan L352T-C offers vivid images with 24-bit color (16.77 million colors) display, 180 cd/m² brightness, and 400:1 contrast ratio. Native resolution is 1024 × 768 and response time a fast 25 ms. Clock, phase, and screen position can be automatically adjusted at the press of a button. A gamma correction function and an sRGB mode facilitate further image adjustment and color control.

The touch panel is built into the monitor and has a touch life of over 225 million touches and optical clarity of 84%. The panel includes a durable antibacterial protectant, making it highly resistant to water, grease, dirt, and static. The monitor is designed to fit into compact spaces with its thin bezels, internal power supply unit, and removable stand for mounting. Dual 1-watt speakers are built in for audio confirmation of touch input.

DVI-D and D-sub mini 15 pin inputs allow for simultaneous connection to computers outfitted with digital or analog graphics boards. A button on the front panel lets the user quickly toggle between input signals when two computers are connected to the monitor at the same time.

The FlexScan L352T-C carries the in-house “EIZO Eco Products 2002” label, signifying that it conforms to a range of eco-friendly criteria in respect of design, manufacture, packaging, and usage, including the introduction of lead-free solder and chrome-free steel plates.

For users in an environment where gloves may be required such as hospitals or factories, EIZO offers the TP1 touch panel pointer for pen touch. The TP1 is sold separately.

Availability

The FlexScan L352T-C will go on sale worldwide in January 2004 through EIZO's network of international distributors. The cabinet comes in a choice of gray or black.

About EIZO

Eizo Nanao Corporation is a leading global manufacturer of high-end visual display products with a wide range of LCD, CRT, and PDP monitors, and Windows-Based Terminals. The image quality, long-term reliability, and innovative features of EIZO monitors and WBTs make them the products of choice in many financial trading rooms, hospitals, back offices, and design studios throughout the world. EIZO is based in Japan and represented in over thirty countries by a network of exclusive distributors.



For more information, please contact:

Eizo Nanao Corporation
153 Shimokashiwano
Matto, Ishikawa 924-8566
Japan
Phone: +81 76 277-6792
Fax: +81 76 277-6793
<http://www.eizo.com/>

###

¹TÜV/GM is a mark for medical devices established by TÜV Rheinland of Germany. TÜV/GM is based on the European Union Medical Device Directive (MDD) EN60601-1, which addresses safety issues in medical devices. TÜV/GM also includes requirements for EMC (electromagnetic compatibility) as stipulated in EN60601-1-2.

FlexScan and EIZO are registered trademarks of Eizo Nanao Corporation.